

Guidance for Jointing 22mm Worktops

Please note 22mm worktops require different joiner bolts to standard 38mm worktops.

Tools required;

- Typically 3 joiner bolts (suitable for 22mm installations) per joint
- Standard Worktop Jig
- Clamps
- 10mm spanner
- Sealant

Installation;

- **Pre- set router blade to a maximum of 15 mm, plus the thickness of the jig**
- Use a hand router with a plunge bit and a worktop jig to produce a mirrored set of joiner bolt cut outs onto both modules to be joined
- The recess for the connector bolts should be NO more than 15 mm into the back face of the worktop
- Make sure you do not over tighten the joiner bolts (avoid using a ratchet spanner)